



OcuLED Light for **OCULUS**



light mounting holes



included
plastic rivets
x2



(lightly push center pin
if removal required)

Quick Install Guide:

1. Mount light into mounting holes as shown here
2. Plug cable into spare USB port in laptop
(NOTE: if installing both Oculus ROV AND OcuLED light at the same time, don't plug them in at once; allow driver installation to complete individually)
3. Wait for drivers to automatically install (Windows 7), or manually drivers if necessary (Windows XP): the drivers are located in the Oculus software package under 'FTDI USB Drivers'. See 'installing drivers' section in the online documentation if you need more instructions <http://www.xaxxon.com/oculus/docs/>



Xaxxon Technologies
div. of Pathway Design & Mfg Inc.
www.xaxxon.com
info@xaxxon.com